Stabilizer System - Cable Guide 6



Configuration Overview | 8.6.5 / 2024.11

			_	_	_	_	
Item Number	Cable Name	Supported Cameras	Artemis '	1 Artemis 2	TRINITY 1	TRINITY 2	360 EVO
K2.0052057	Power Cable 12V/12V In - 12V Hot Swap Out, BHM	A special power management cable that connects the batteries to the bottom stage / sled of the ARTEMIS 2 Live. There are three versions available: 2 x 12V in - 12V Hot Swap out (K2.0052057), 2 x 12V in - 12V &24V out (K2.0052139), 1 x 12V & 24V in - 12V &24V out (K2.0052140)	X	Artemis 2 Live only	X	X	X
K2.0052139	Power Cable 12V/12V In - 12V/24V Out, BHM	A special power management cable that connects the batteries to the bottom stage / sled of the ARTEMIS 2 Live. There are three versions available: 2 x 12V in - 12V Hot Swap out (K2.0052057), 2 x 12V in - 12V &24V out (K2.0052139), 1 x 12V & 24V in - 12V &24V out (K2.0052140)	X	Artemis 2 Live only	X	X	X
K2.0052140	Power Cable 12V/24V In - 12V/24V Out, BHM	A special power management cable that connects the batteries to the bottom stage / sled of the ARTEMIS 2 Live. There are three versions available: $2 \times 12V$ in - 12V Hot Swap out (K2.0052057), $2 \times 12V$ in - 12V &24V out (K2.0052139), $1 \times 12V$ & 24V in - 12V &24V out (K2.0052140)	X	Artemis 2 Live only	X	X	X